Automatic Veterinary Syringes

ThaMa Fowl Pox Vaccinator

The Automatic Fowl Pox Vaccinator is made of the best materials. All parts are oil-proof and non-corrosive.







Operating Instructions:

1. Open the end front cap (No. 32) of the Vaccinator.
2. Fill the vaccine direct to the glass barrel.
3. Close the end front cap (No. 32) tight to the glass barrel.
4. Every squeezing on the upper handle, bring a drop direct to the chicken wing.
5. After use; open the end front cap dismantle the glass barrel and flush the complete vaccinator with clear water.
6. Sterilize; you may sterilize the vaccinator parts up to 125ºC before the next use.

24-6069
Ver. 5/2019

31 - Syringe body
32 - End front cap
33 - Rubber stopper
34 - Neoprene washer
35 - Needle
36 - Needle screw
38 - Glass barrel
311 - Needle shaft
313 - Body cover
315 - Handle spring
317 - Upper handle
399 - Spare parts kit (33, 34)

When ordering:

Please add the vaccinator volume 1cc or 2cc